



APPLICATION INSTRUCTIONS OF CLAD REX LAMINATED SHEETS

Our laminated sheets can be applied over finished walls or unfinished drywall. Time and money will be saved by eliminating demolition or finishing new drywall.

Cuts can be made with any Dremel or similar rotary cutter with a diamond blade.

We recommend the following constructive adhesives that will grab quickly when applying our sheets to vertical surfaces. The adhesive should be spread evenly across the sheet back and pressure applied for a few minutes until the sheet grabs onto the wall.

3M 5200

LocTite PL 3X

Gorilla Construction Adhesive

ASI 5900 (American Sealants)